

# Pump Naming Table

## PMV Part No. Reference

## PMV Part Number

## PMV Part No. Reference

Oil 05 = 5:1  
06 = 6:1  
10 = 10:1  
Grease 50 = 50:1

Pump Ratio

3 = 3"  
4 = 4.25"

Air Motor Size

V=PMV

Pump Series

Drum/Tank Size

00S = STUB  
016 = 16 Gallon  
055 = 55 Gallon  
275 = 275 Gallon  
035 = 25-50 lb.  
120 = 120 lb.  
400 = 400 lb.

Pump Mount

000 = Bare Pump  
BB = Bung Bushing  
DC = Drum Cover  
LT = Lube Truck with Drum Cover  
LB = Lube Truck with Bung Bushing  
WM = Wall Mount  
SU = Stub Universal  
HF = Hoist/Follower  
HR = Hoist/Follower/Runaway

### Description

### Included with Packages

5:1 Bare Pump	V	3	05	000	000	
5:1 Stub/Universal Pump	V	3	05	00S	SU	Bung Bushing, Air Cplr./Nipple, Air Hose, Fluid Hose
5:1 55 Gal Pump	V	3	05	055	BB	Bung Bushing, Air Cplr./Nipple, Air Hose, Fluid Hose, Down Tube
5:1 16 Gal Pump	V	3	05	016	DC	Drum Cover, Air Cplr./Nipple, Air Hose, Fluid Hose, Down Tube
5:1 275 Gal Pump	V	3	05	275	BB	Bung Bushing, Air Cplr./Nipple, Air Hose, Fluid Hose, Down Tube
5:1 Wall Mount Pump	V	3	05	00S	WM	Wall Mount Kit, Suction Kit, Air Cplr./Nipple, Air Hose, Fluid Hose
5:1 55 Gal Lube Truck Pump	V	3	05	055	LT	Drum Cover, Tie Rods/Eye Bolts, Down Tube, Air Cplr./Nipple, Air Hose
50:1 Pump, 3", 120 Lb Bare	V	3	50	120	000	
50:1 Pump, 3", 400 Lb Bare	V	3	50	400	000	
50:1 3" 120 Lb Stationary Pkg	V	3	50	120	DC	Drum Cover, Follower, Air Cplr./Nipple, Air Hose, Grease Hose, Outlet Swivel
50:1 3" 400 Lb Stationary Pkg	V	3	50	400	DC	Drum Cover, Air Cplr./Nipple, Air Hose, Grease Hose, Outlet Swivel
50:1 3" 120Lb Hoist/Follower Pkg	V	3	50	120	HF	Hoist, Follower/Primer, Air Cplr./Nipple, Air Hose, Grease Hose
50:1 3" 400Lb Hoist/Follower Pkg	V	3	50	400	HF	Hoist, Follower/Primer, Air Cplr./Nipple, Air Hose, Grease Hose
50:1 3" 120Lb Lube Truck Pkg	V	3	50	120	LT	Drum Cover, Tie Rods/Eye Bolts, Air Coupler/Nipple, Outlet Swivel
50:1 3" 400Lb Lube Truck Pkg	V	3	50	400	LT	Drum Cover, Tie Rods/Eye Bolts, Air Coupler/Nipple, Outlet Swivel
6:1 Bare Pump	V	4	06	000	000	
6:1 Stub Pump	V	4	06	00S	SU	Air Coupler/Nipple, Air Hose, Fluid Hose
6:1 Wall Mount Pump	V	4	06	00S	WM	Wall Mount Kit, Suction Kit, Air Coupler/Nipple, Air Hose, Fluid Hose
10:1 Bare Pump	V	4	10	000	000	
10:1 Stub/Universal Pump	V	4	10	00S	SU	Bung Bushing, Air Cplr./Nipple, Air Hose, Fluid Hose
10:1 55 Gal Pump W/ Drum Cvr	V	4	10	055	DC	Drum Cover, Air Cplr./Nipple, Air Hose, Fluid Hose, Down Tube
10:1 55 Gal Pump W/ Bung Bshng	V	4	10	055	BB	Bung Bushing, Air Cplr./Nipple, Air Hose, Fluid Hose, Down Tube
10:1 Wall Mount Pump	V	4	10	00S	WM	Wall Mount Kit, Suction Kit, Air Coupler/Nipple, Air Hose, Fluid Hose
10:1 55 Gal Lube Truck Pump W/Dc	V	4	10	055	LT	Drum Cover, Tie Rods/Eye Bolts, Down Tube, Air Coupler/Nipple, Air Hose
10:1 55 Gal Lube Truck Pump W/Bung Bshng	V	4	10	055	LB	Bung Bushing, Tie Rods/Eye Bolts, Down Tube, Air Coupler/Nipple, Air Hose
50:1 Pump, 4.25", 120 Lb Bare	V	4	50	120	000	
50:1 Pump, 4.25", 400 Lb Bare	V	4	50	400	000	
50:1 4.25" 120 Lb Stationary Pkg	V	4	50	120	DC	Drum Cover, Follower, Air Cplr./Nipple, Air Hose, Grease Hose, Outlet Swivel
50:1 4.25" 400 Lb Stationary Pkg	V	4	50	400	DC	Drum Cover, Follower, Air Cplr./Nipple, Air Hose, Grease Hose, Outlet Swivel
50:1 4.25" 400Lb Hoist/Follower Pkg	V	4	50	400	HF	Hoist, Follower/Primer, Air Cplr./Nipple, Air Hose, Grease Hose
50:1 4.25" 400Lb Hoist/Follower/Runaway Pkg	V	4	50	400	HR	Hoist, Follower/Primer, Air Cplr./Nipple, Air Hose, Grease Hose, Runaway Ctrl
50:1 4.25" 120Lb Lube Truck Pkg	V	4	50	120	LT	Drum Cover, Tie Rods/Eye Bolts, Air Coupler/Nipple, Outlet Swivel
50:1 4.25" 400Lb Lube Truck Pkg	V	4	50	400	LT	Drum Cover, Tie Rods/Eye Bolts, Air Coupler/Nipple, Outlet Swivel
50:1 3" 25-50Lb Bare Pump	V	3	50	035	000	
50:1 25-50 Lb Portable W/Pail Cvr				9989		Pail Cover, Air Coupler/Nipple, Grease Hose, Control Valve, Swivel
50:1 120Lb Portable W/Caster Base				9917		Drum Cover, Follower, Air Cplr./Nipple, Grease Hose, Control Vlv., Caster Base